
lĕvoit

USER MANUAL

LVAC-200 Cordless Stick Vacuum



Questions or Concerns?

Please contact us at **support.uk@levoit.com**

Table of Contents

Package Contents	**2**
Specifications	**2**
Safety Instructions	**3**
Getting to Know Your Vacuum	**6**
Controls	**7**
Using Your Vacuum	**7**
Care & Maintenance	**9**
Cleaning	**12**
Storage	**15**
Troubleshooting	**16**
Warranty Information	**17**
Customer Support	**19**

Package Contents

1 x Vacuum Body
1 x Long Stick
1 x Short Stick
1 x Vacuum Head
1 x 2-in-1 Crevice Tool
1 x 2-in-1 Pet Tool
1 x Wall Mount
2 x Screw
2 x Wall Anchor
1 x Charger
1 x User Manual

Specifications

Model	LSV-V201-WUK	
Battery Input	22.2V⎓ 2200mAh Li-ion battery	
Rated Power	180W*	
Charging Input	100–240V~ 50/60Hz 0.8A	
Dimensions	25.0 x 19.5 x 110.0 cm / 9.8 x 7.7 x 43.3 in	
Battery Operating Conditions	Charging Temperature: 4°–40°C / 39.2°–104°F Storage Temperature: 0°–25°C / 32°–77°F Storage Humidity: 65%±20%	
Runtime (Using Crevice Tool or Pet Tool)**	Eco Mode	50 minutes
	Mid Mode	20 minutes
	Turbo Mode	12 minutes
Runtime (Using Vacuum Head)**	Eco Mode	30 minutes
	Mid Mode	20 minutes
	Turbo Mode	12 minutes
Charging Time	Approximately 3 hours	

***Note:** May vary +/- 10%.*
****Note:** Runtime is the result of testing at room temperature.*

IMPORTANT SAFETY INSTRUCTIONS

When using this vacuum, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

WARNING – To reduce the risk of fire, electric shock, or injury:

- **CAUTION:** Risk of injury. Roller brush may start unexpectedly. Remove battery pack before cleaning or servicing.
- **Do not** leave the vacuum unattended while it is on. Unplug from outlet when not charging and before servicing.
- **Do not** use outdoors or on wet surfaces.
- Children shall not play with the appliance.
- **Do not** allow to be used as a toy. Close attention is necessary when used by or near children.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Cleaning and user maintenance shall not be made by children without supervision.
- **Only** use the vacuum as described in this manual.
- Use **only** manufacturer's recommended attachments.
- **Do not** use your vacuum if it is damaged or not working correctly, or if the charger or plug is damaged. **Do not** try to repair it yourself. Contact **Customer Support** (see page 19).
- **Do not** handle the charger or vacuum with wet hands.
- **Do not** put any object into any opening. **Do not** use the vacuum with any opening blocked. Keep free of dust, lint, hair, or anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts.
- Use extra care when cleaning on stairs.
- **Do not vacuum the following** (or use where they may be present):
    - Sharp objects such as glass shards, metallic nails, metal paper clips, or pins;
    - Ultrafine particles such as lime, cement, sawdust, gypsum powder, or ashes;
    - Hazardous materials or chemicals such as solvents, drain cleaner, strong acids, or strong alkalis.
- **Always** turn the vacuum off before connecting or disconnecting the stick, nozzles, brushes, or vacuum head.
- **Do not** vacuum water or any liquids.
- **Do not** vacuum anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- **Do not** use without dust bin and filters in place.
- **Do not** point the vacuum at any person or animal while it is on.
- Store the vacuum on a small stand or hang it from the wall.
- **Do not** use the vacuum in temperatures above 40°C (104°F) or below 4°C (39.2°F).

Battery & Charger

WARNING: Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- **Do not** pull or carry the vacuum by the charging cable, use the cable as a handle, close a door on the cable, or pull the cable around sharp edges or corners. **Do not** run any appliance over the cable.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the appliance. Carrying the appliance with your finger on the switch or energizing appliance that have the switch on invites accidents.
- Disconnect the battery pack from the appliance before making any adjustments, changing accessories, or storing appliance. Such preventive safety measures reduce the risk of starting the appliance accidentally.
- **Do not** unplug by pulling on cord. To unplug, grasp the plug, not the cord. Turn off all controls before unplugging.
- **Never** place the charger or its cable near any heat source.
- Keep the charging cable out of areas where people walk often. Place the cable where it will not be tripped over.
- **Do not** use the charger to charge other appliances besides this vacuum.
- **Only** recharge the vacuum with the charger specified by Arovast Corporation. A charger that is suitable for one type of appliance may create a risk of fire when used with a different battery pack. For use **only** with the ZD024M260085BS adapter manufactured by E-TEK Electronics Manufactory Co., LTD. For more information, please contact **Customer Support** (see page 19).
- **Only** use the battery pack specifically designed for this vacuum. Use of any other battery packs may create a risk of injury and fire. For use **only** with the LSV-V201B-WUS battery pack manufactured by Suzhou Lishen Energy Science & Technology Co., Ltd. For more information, please contact **Customer Support** (see page 19).
- When the battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws, or other small metal objects that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.
- Under abusive conditions, liquid may be ejected from the battery. Avoid contact. If contact occurs, flush with water. If liquid contacts eyes, immediately flush with water and seek medical help. Liquid ejected from the battery may cause irritation or burns.
- **Do not** use the battery pack or vacuum if they are damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosions, or risk of injury.
- Have servicing performed **only** by a qualified repair person using identical replacement parts. This will ensure that the safety of the vacuum is maintained.
- **Do not** modify or attempt to repair the vacuum or the battery pack except as indicated in the manual.

- **Do not** expose the battery pack or vacuum to fire or excessive temperatures. The battery used in this device may present a risk of fire or chemical burn if mistreated. **Do not** disassemble, short contacts, heat above 60°C (140°F), or incinerate. Exposure to fire or temperatures above 130°C (266°F) may cause an explosion.
- Follow all charging instructions and **do not** charge the battery pack or vacuum outside of the temperature range specified in the instructions. Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire.
- **WARNING: Do not** use with non-rechargeable batteries.
- **WARNING:** For the purposes of recharging the battery, **only** use detachable supply unit provided with this appliance.

SAVE THESE INSTRUCTIONS

NOT FOR COMMERCIAL USE HOUSEHOLD USE ONLY



This product is RoHS compliant.

This product is in compliance with Directive 2011/65/EU, and its amendments, on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

Instructions for Users on Removal, Recycling and Disposal of Used Batteries


To remove the batteries from your equipment or remote control, reverse the procedure described in the owner's manual for inserting batteries. For products with a built-in battery that lasts for the lifetime of the product, removal may not be possible for the user. In this case, recycling or recovery centers handle the dismantling of the product and the removal of the battery. If, for any reason, it becomes necessary to replace such a battery, this procedure must be performed by authorized service centers. In the European Union and other locations, it is illegal to dispose of any battery with household trash. All batteries must be disposed of in an environmentally sound manner. Contact your local waste-management officials for information regarding the environmentally sound collection, recycling and disposal of used batteries.

WARNING: Danger of explosion if battery is incorrectly replaced. To reduce risk of fire, explosion or leakage of flammable liquid/gas, don't disassemble, crush, puncture, short external contacts, expose to temperature above 60°C (140°F), sunshine or like, expose to extremely low air pressure or dispose of in fire or water. Replace only with specified batteries. The symbol indicating 'separate collection' for all batteries and accumulators shall be the crossed-out wheeled bin shown below:



GETTING TO KNOW YOUR VACUUM

A. On/Off Button
B. Suction Mode Button
C. Vacuum Body
D. Pre-Motor Filters
E. Battery Indicator Lights
F. Battery
G. Battery Release Button
H. Metal Filter
I. Dust Bin
J. Lid Release Button
K. Dust Bin Release Button
L. Vacuum Body Release Button
M. Charger
N. 2-in-1 Crevice Tool
O. 2-in-1 Pet Tool
P. Short Stick
Q. Long Stick
R. Vacuum Head Release Button
S. Vacuum Head
T. LED Lights
U. Roller Brush
V. Roller Brush Release Button
W. Vacuum Handle
X. Charging Port (on the battery)
Y. Post-Motor Filter
Z. Screws
AA. Wall Anchors
BB. Wall Mount



CONTROLS

On/Off Button

- Turns on/off the vacuum.

Suction Mode Button

- Cycles through Eco Mode, Mid Mode and Turbo Mode.
- The vacuum will default to Eco Mode. Press once for Mid Mode. Press again for Turbo Mode. Press again to switch back to Eco Mode.
- Eco Mode is suitable for daily cleaning.
- Mid Mode is suitable for strong cleaning.
- Turbo Mode is suitable for deep cleaning.

Battery Indicator Lights

- Indicate the battery level when you are using the vacuum.

Battery Indicator Light Chart (During Use)

Battery Level	Battery Indicators
70–100%	
35–70%	
10–35%	
0–10%	




Figure 1.1

USING YOUR VACUUM

1. Build the vacuum stick by aligning the dots on the long stick and short stick, then push together until they lock in place. ***[Figure 1.1]***
2. Attach the vacuum head or a nozzle attachment to the bottom of the stick, then attach the vacuum body to the top of the stick. ***[Figure 1.2]***

   Note: *There is a clicking sound when the parts are properly joined together.*

3. Charge the vacuum (see page 9).

   Note: *Fully charge the battery before first use.*

4. Press the On/Off Button to turn the vacuum on. The vacuum will default to Eco Mode.
5. Press the Suction Mode Button to switch between Eco Mode, Mid Mode and Turbo Mode.
6. Press the On/Off Button to turn the vacuum off.




Figure 1.2

Nozzle Attachments

Your vacuum comes with nozzle attachments to help you tackle daily or weekly cleanup job.

2-in-1 Crevice Tool

- Press button to slide bristles up/down and switch between crevice tool and dusting brush. ***[Figure 1.3]***
- Use the crevice tool to clean hard-to-reach places like crevices in furniture and corners of a room or car.
- Use the dusting brush to clean dust and hard surfaces like mantels or baseboards.




Figure 1.3

2-in-1 Pet Tool

- Use the brush head to clean fur off soft upholstery or pets.
- Remove the brush head to use the fur removal tool which loosens hair on fabric and carpet. ***[Figure 1.4]***




Figure 1.4

To use a nozzle attachment:

1. Press and hold the Vacuum Body Release Button and gently pull the vacuum body from the stick.
2. Slide the nozzle attachment onto the vacuum body. ***[Figure 1.5]***
3. Optionally, leave the stick attached to the vacuum body and press the Vacuum Head Release Button to remove the vacuum head. Then, attach the nozzle attachment to the end of the stick. ***[Figure 1.6]***

Note: *You can also attach the vacuum body directly to the vacuum head.* ***[Figure 1.7]***




Figure 1.5




Figure 1.6




Figure 1.7

CARE & MAINTENANCE

Battery Installation

1. Turn the vacuum off. Press the Battery Release Button and remove the battery.
2. To reinstall, slide the battery into the slot in the vacuum body. ***[Figure 2.1]*** There will be a clicking sound when the battery is properly installed.

Note:

- *To maintain the life of the battery, store the vacuum in a cool, dry place.*
- *Store the battery in a semi-charged state (at least 2 battery indicator lights) and maintain this by charging the battery every 3 months.*




Figure 2.1

Charging the Vacuum

Your vacuum uses a 2,200mAh Li-ion battery. Use the included charger to charge the vacuum.

Note:

- *Make sure the vacuum is turned off before charging.*
- *Please charge your vacuum after each use.*

1. Install the wall mount by screwing it into the wall near a power outlet. ***[Figure 2.2]***

Note:

- *The wall mount must be high enough on the wall to allow the vacuum to stand up.*
- *Make sure that the wall is free of gas pipes, water pipes, electrical cables, and wires.*




Figure 2.2

2. Hang the vacuum on the wall mount. ***[Figure 2.3]***
3. Insert the charger into the charging port on the battery. ***[Figure 2.3]***
4. Plug the charger into the outlet. The battery lights will blink while charging. ***[Figure 2.3]***
5. When the vacuum is fully charged, the 3 battery indicator lights will turn solid for 5 minutes, then turn off.




Figure 2.3

Alternatively, the battery can be charged separate from the vacuum body.

1. Press the Battery Release Button to remove the battery.
2. Insert the charger into the charging port on the battery. ***[Figure 2.4]***
3. Plug the charger into an outlet. The battery indicator lights will blink while charging.
4. When the vacuum is fully charged, the 3 battery indicator lights will turn solid for 5 minutes, then turn off.




Figure 2.4

Battery Indicator Light Chart (While Charging)

Battery Level	Battery Indicators
0–35%	
35–70%	
70–100%	
100%	

Warning:

- **Only** charge the battery with the charger specified by Levoit.
- If you are not using the battery for an extended period, store it in a cool, dry place.
- Store the battery in a semi-charged state (at least 2 battery indicator lights) and maintain this by charging the battery every 3 months.
- For more information, please contact **Customer Support** (see page 19).

Emptying the Dust Bin

When dust in the dust bin reaches the MAX line, empty the dust bin.

> ***Warning: Do not*** *overfill the dust bin. If the dust bin is too full, it may affect the performance of the vacuum.*

1. Turn the vacuum off. Remove the dust bin by pressing the Dust Bin Release Button.
2. Hold the dust bin over a trash can and press the Lid Release Button. ***[Figure 2.5]*** Use caution, as the lid will open when the release button is pushed.

> ***Note:*** *Holding the dust bin inside a trash can prevents dust from spilling out.*

3. Empty out debris and dirt, then close the lid.

Alternatively, you can remove the vacuum body to empty the dust bin.

1. Remove the vacuum body by pressing the Vacuum Body Release Button.
2. Hold the dust bin over a trash can and press the Lid Release Button. ***[Figure 2.5]***




Figure 2.5

CLEANING

Cleaning the Vacuum Body

1. Turn the vacuum off.
2. Wipe the outside of the vacuum down with a damp cloth.
3. Allow the vacuum to completely dry before using.

***Warning: Do not** allow water to enter the internal parts or motor of the vacuum.*




Figure 3.1

Cleaning the Dust Bin & Metal Filter

1. Make sure the vacuum is off and the dust bin is completely empty before cleaning (see **Emptying the Dust Bin**, page 11).
2. Press the Dust Bin Release Button and pull the dust bin to remove it. ***[Figure 3.1]*** Empty out any remaining dust and debris, and remove any hair tangled around the metal filter.
3. Remove the pre-motor filters from the top of the dust bin. Set aside or wash the pre-motor filters (see **Cleaning the Pre-Motor & Post-Motor Filters**, page 13).
4. Rotate the metal filter counterclockwise to remove it. ***[Figure 3.2]***
5. Rinse the dust bin and metal filter with water and allow them to dry. Make sure the parts are completely dry before using.
6. Reattach the metal filter and replace the pre-motor filters. Attach the dust bin to the vacuum body.

***Warning: Do not** allow water to enter the internal parts or motor of the vacuum.*




Figure 3.2

Cleaning the Pre-Motor & Post-Motor Filters

To maintain the performance of your filters, they should be routinely washed and replaced.

- If you notice decreased suction power, or the filter is visibly dirty, clean the filter immediately.
- The pre-motor filters (foam filter and felt filter) should be washed at least once a month and replaced every 3 months.
- The post-motor filter should be washed at least once a year.
- **Do not** put filters in a dishwasher, washing machine, tumble dryer, oven, or microwave, or place near an open flame.
- **Never** operate the vacuum without the dust bin or filters properly installed.
- Frequent use may require cleaning the filters more often. Cleaning the filters regularly helps maintain your vacuum's cleaning performance.
- You may need to replace the filters more frequently depending on your use and environment.
- If the surrounding humidity is high, please allow the filters to air-dry for a longer period of time before reinstalling them back into the vacuum.

Replacement Filters:

- To maintain the performance of your vacuum, **only** use official Levoit filters. For more information, contact **Customer Support** (see page 19).

Pre-Motor Filters

To maintain the performance of your filters, they should be routinely washed and replaced.

1. Press the Dust Bin Release Button to remove the dust bin. ***[Figure 3.3]***
2. Remove the two pre-motor filters (foam filter and felt filter). ***[Figure 3.4]***
3. Clean the pre-motor filters with water. Allow the filters to air-dry completely under the sun or in a dry, ventilated place before reinstallation.
4. Replace the foam filter, followed by the felt filter.

Note: *Make sure the felt filter has the ribbon-handle side facing outward when you insert the filter.*

5. Place the dust bin back onto the vacuum body.




Figure 3.3




Figure 3.4

Post-Motor Filter

1. Press the Dust Bin Release Button to remove the dust bin. ***[Figure 3.5]***
2. Pull out the post-motor filter (high-efficiency paper) from the vacuum body. ***[Figure 3.6]***
3. If necessary, run post-motor filter under running water to wash it. ***[Figure 3.7]*** Allow the filter to air-dry completely under the sun or in a dry, ventilated place before reinstallation.
4. Push the post-motor filter back in the vacuum body until you hear a click, then replace the dust bin.




Figure 3.5




Figure 3.6




Figure 3.7

Cleaning the Roller Brush

Periodically check the roller brush for hair or debris. The roller brush will automatically shut off if it is blocked or jammed.

1. Turn the vacuum off. Detach the vacuum head from the stick by pressing the Vacuum Head Release Button.
2. Press the Roller Brush Release Button, slide the side panel up to open, then pull out the roller brush. ***[Figure 3.8]***
3. If the roller brush is jammed, carefully use a pair of scissors or a sharp knife to remove any hair or debris tangled around the roller brush.
4. Insert the roller brush back into the vacuum head. Slide the side panel down to lock it in place.






Figure 3.8

STORAGE

When the vacuum is not in use, store it on the wall mount:

1. Screw the wall mount into the wall near a power outlet (see **Charging the Vacuum**, page 9).
2. Hang the vacuum on the wall mount.

Note:

- ***Always*** *store the vacuum on the wall mount.*
- *If storing for long periods of time, periodically charge the battery to preserve the life of the battery.*

Disposing of the Battery

- The battery contains materials that are harmful to the environment and must be removed from the vacuum before it is discarded.
- When removing the battery, the vacuum must be turned off.
- Discarded batteries should be handled properly. **Do not** put batteries into fire, water, or soil.
- If battery leakage touches skin or clothing, flush with water immediately to avoid skin injury and seek medical help.

TROUBLESHOOTING

Problem	Possible Solution
Vacuum will not turn on.	The battery is not installed correctly (see **Battery Installation**, page 9).
	Recharge the vacuum (see **Charging the Vacuum**, page 9).
	The vacuum motor overheated. Empty the dust bin and check for blockage inside the vacuum head and stick. Remove any blockage and clean the filters (see **Cleaning**, page 12). Allow the vacuum to cool for 1 hour before turning it back on.
Vacuum is not charging.	The charger is not properly plugged in or you are using the wrong charger. Use the provided Levoit charger **only** (see **Charging the Vacuum**, page 9).
Roller brush is not turning (LED lights flash).	Clean the roller brush and remove any debris blocking the brush (see **Cleaning the Roller Brush**, page 14).
Vacuum makes an abnormal noise.	Clean the roller brush and remove any debris blocking the brush (see **Cleaning the Roller Brush**, page 14).
	Check for blockage inside the vacuum body, vacuum head, and stick. Remove any blockage (see **Cleaning**, page 12).
Vacuum has low suction power.	Battery may be low. Recharge the battery to full charge (see **Charging the Vacuum**, page 9).
	Clean the roller brush and remove any debris blocking the brush (see **Cleaning the Roller Brush**, page 14).
	The dust bin and filters may be full. Empty the dust bin and clean the filters (see **Cleaning**, page 12).
	Check for blockage inside the vacuum body, vacuum head, and stick. Remove any blockage (see **Cleaning**, page 12).
The LED lights and battery indicator lights flash.	The dust bin and filters may be full. Empty the dust bin and clean the filters (see **Cleaning**, page 12).
	Check for blockage inside the vacuum body, vacuum head, and stick. Remove any blockage (see **Cleaning**, page 12).
Battery indicator lights flash red lights.	The battery may be overheating. Remove the battery and place in a room-temperature environment to cool down. If it still flashes red, contact **Customer Support** (see page 19).

Problem	Possible Solution
Vacuum releases a bad or unusual smell.	The environment's relative humidity may be high or the vacuum may have absorbed water and caused the filter to grow mold. Replace the filters (contact **Customer Support**, page 19).
	The filters may be dirty. Clean the filters (see **Cleaning**, page 12).
	The dust bin may be dirty. Empty and clean the dust bin (see **Cleaning**, page 12).

If your problem is not listed, please contact **Customer Support** (see page 19).

WARRANTY INFORMATION

Product Name	Levoit LVAC-200 Cordless Stick Vacuum
Model	LSV-V201-WUK
For your own reference, we strongly recommend that you record your order ID and date of purchase.	
Order ID	
Date of Purchase	

Levoit Limited Product Warranty

Two (2) Year* Limited Consumer Product Warranty

VeSync (UK) Limited ("VeSync") warrants that the product shall be free from defects in material and workmanship for a period of **2 years from the date of original purchase** ("Limited Warranty Period"), provided the product was used in accordance with its use and care instructions (e.g., in the intended environment and under normal circumstances). ***This warranty does not limit your rights as may be mandated or granted by the applicable national or regional consumer protection laws in your region, in which cases the Limited Warranty Period is extended pursuant to the applicable requirements.***

Your Limited Warranty Benefits

During the Limited Warranty Period and subject to this limited Warranty Policy, VeSync will, in its sole and exclusive discretion, either (i) refund the purchase price if the purchase was made directly from the online Levoit store, (ii) repair any defects in material or workmanship, (iii) replace the product with another product of equal or greater value, or (iv) provide store credit in the amount of the purchase price.

Who is Covered?

This limited warranty extends only to the original consumer purchaser of the product and is not transferable to any subsequent owner of the product, regardless of whether the product transferred ownership during the specified term of the limited warranty. The original consumer purchaser must provide verification of the defect or malfunction and proof of the date of purchase to claim the Limited Warranty Benefits.

Be Aware of Unauthorized Dealers or Sellers

This limited warranty does not extend to products purchased from unauthorized dealers or sellers. VeSync's limited warranty only extends to products purchased from authorized dealers or sellers that are subject to VeSync's quality controls and have agreed to follow its quality controls. Please be aware, products purchased from an unauthorized website or dealer may be counterfeit, used, defective, or may not be designed for use in your country. You can protect yourself and your products by making sure you only purchase from VeSync or its authorized dealers.

If you have any questions about a specific seller, or if you think you may have purchased your product from an unauthorized seller, please contact our Customer Support Team.

What's Not Covered?

- Normal wear and tear, including normal wearing parts, such as dust bin, filter, roller brush, battery, and power cord, or carpet or floor damage due to misuse.
- If the proof-of-purchase has been altered in any way or is made illegible.
- If the model number, serial number or production date code on the product has been altered, removed or made illegible.
- If the product has been modified from its original condition.
- If the product has not been used in accordance with directions and instructions in the user manual.
- Damages caused by connecting peripherals, additional equipment or accessories other than those recommended in the user manual.
- Damages or defects caused by accident, abuse, misuse, or improper or inadequate maintenance.
- Damages or defects caused by service or repair of the product performed by an unauthorized service provider or by anyone other than VeSync.
- Damages or defects occurring during commercial use, rental use, or any use for which the product is not intended.
- If the unit has been damaged, including but not limited to damage by animals, lightning, abnormal voltage, fire, natural disaster, transportation, dishwasher, or water (unless the user manual expressly states that the product is dishwasher-safe).
- Incidental and consequential damages.
- Damages or defects exceeding the cost of the product.

Claiming Your Limited Warranty Service in 5 Simple Steps:

1. Make sure your product is within the specified limited warranty period.
2. Make sure you have a copy of the invoice and order ID or proof-of-purchase.
3. Make sure you have your product. **DO NOT** dispose of your product before contacting us.
4. Contact our Customer Support Team.
5. Once our Customer Support Team has approved your request, please return the product with a copy of the invoice and order ID.

Sole and Exclusive Remedy

THE FOREGOING LIMITED WARRANTY CONSTITUTES VESYNC'S EXCLUSIVE LIABILITY, AND YOUR SOLE AND EXCLUSIVE REMEDY, FOR ANY BREACH OF ANY WARRANTY OR OTHER NONCONFORMITY OF THE PRODUCT COVERED BY THIS LIMITED PRODUCT WARRANTY STATEMENT. THIS LIMITED WARRANTY IS EXCLUSIVE, AND IN LIEU OF ALL OTHER WARRANTIES. NO EMPLOYEE OF VESYNC OR ANY OTHER PARTY IS AUTHORIZED TO MAKE ANY WARRANTY IN ADDITION TO THE LIMITED WARRANTY IN THIS LIMITED PRODUCT WARRANTY STATEMENT.

Disclaimer of Limited Warranties

TO THE FULLEST EXTENT PROVIDED BY APPLICABLE LAW, EXCEPT AS WARRANTED IN THIS LIMITED PRODUCT WARRANTY POLICY, VESYNC PROVIDES THE PRODUCTS YOU PURCHASE FROM VESYNC "AS IS" AND VESYNC HEREBY DISCLAIMS ALL WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, STATUTORY, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, AND FITNESS FOR PARTICULAR PURPOSE.

Limitations of Liability

TO THE FULLEST EXTENT PROVIDED BY APPLICABLE LAW, IN NO EVENT WILL VESYNC, ITS AFFILIATES, OR THEIR LICENSORS, SERVICE PROVIDERS, EMPLOYEES, AGENTS, OFFICERS, OR DIRECTORS BE LIABLE FOR:

(a) DAMAGES OF ANY KIND ARISING OUT OF OR IN CONNECTION WITH PRODUCTS PURCHASED FROM VESYNC IN EXCESS OF THE PURCHASE PRICE PAID BY THE PURCHASER FOR SUCH PRODUCTS, OR

(b) INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES EVEN IF VESYNC OR ONE OF ITS SUPPLIERS HAS BEEN ADVISED OF THE POSSIBILITY OR LIKELIHOOD OF SUCH DAMAGES.

AND REGARDLESS OF WHETHER CAUSED BY TORT (INCLUDING NEGLIGENCE), BREACH OF CONTRACT, OR OTHERWISE. OUR LIABILITY SHALL UNDER NO CIRCUMSTANCES EXCEED THE ACTUAL AMOUNT PAID BY YOU FOR THE DEFECTIVE PRODUCT, NOR SHALL WE UNDER ANY CIRCUMSTANCES BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR PUNITIVE DAMAGES OR LOSSES, WHETHER DIRECT OR INDIRECT.

EXCEPT AS COVERED BY THIS LIMITED PRODUCT WARRANTY STATEMENT, VESYNC SHALL NOT BE LIABLE FOR COSTS ASSOCIATED WITH THE REPLACEMENT OR REPAIR OF PRODUCTS PURCHASED FROM IT, INCLUDING, BUT NOT LIMITED TO, LABOR, INSTALLATION, OR OTHER COSTS INCURRED BY THE USER AND, IN PARTICULAR, ANY COSTS RELATING TO THE REMOVAL OR REPLACEMENT OF ANY PRODUCT.

Other Rights You May Have

SOME JURISDICTIONS DO NOT ALLOW FOR: (1) EXCLUSION OF IMPLIED WARRANTIES; (2) LIMITATION ON THE DURATION OF IMPLIED WARRANTIES; AND/ OR (3) EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES; SO THE DISCLAIMERS IN THIS POLICY MAY NOT APPLY TO YOU. IN THESE JURISDICTIONS YOU HAVE ONLY THE IMPLIED WARRANTIES THAT ARE EXPRESSLY REQUIRED TO BE PROVIDED IN ACCORDANCE WITH APPLICABLE LAW. THE LIMITATIONS OF WARRANTIES, LIABILITY, AND REMEDIES APPLY TO THE MAXIMUM EXTENT PERMITTED BY LAW.

ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, YOU MAY HAVE OTHER RIGHTS IN YOUR JURISDICTION. THIS STATEMENT OF LIMITED WARRANTY IS SUBJECT TO APPLICABLE LAWS THAT APPLY TO YOU AND THE PRODUCT. PLEASE REVIEW THE LAWS IN YOUR JURISDICTION TO UNDERSTAND YOUR RIGHTS FULLY.

Changes to this policy

We may change the terms and availability of this limited warranty at our discretion, but any changes will not be retroactive.

This warranty is made by:
VeSync (UK) Limited
Unit G2 Havenside Industrial Estate, Fishtoft Road, Boston, England, PE21 0AH

CUSTOMER SUPPORT

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

Email: support.uk@levoit.com

*Please have your order invoice PDF or screenshot(s) ready before contacting Customer Support.

levoit

A5_24K22_uk